


Complete Ramp-Hold Operating Instructions



Sentry 2.0

Digital Temperature Controller

See pages 24 - 25 for instructions on upgrading your DTC 100, 600, 800 or 1000 series board to the Sentry.



Program (pg 8)

From IdLE, press 4.
Select stored program (1 - 4). Enter rate, temperature, and hold for each segment.

Edit a Program (pg 13)

During firing, press 4.
Change the current segment temperature. Press Enter. Change the hold. Press Enter. The kiln will continue firing.

Alarm (pg 12)

From IdLE or during firing, press 7.
Enter a temperature. When alarm sounds during firing, press Enter.

Enter/Start (pg 8)

1) Press Enter/Start after each step in programming a firing.
2) Press Enter/Start once from **IdLE** to begin firing.

Options (pg 14-18)

From IdLE, press 0. Press Enter for option displayed.

TCOS Thermocouple Offset
Change the thermocouple temperature. (Pg 14)

CHG- Select °F or °C. (Pg 15)

TC Thermocouple Type Select Type K, S or R. (Pg 15)

AOP 1 AOP 2 AOP Outlet
Select vent fan or alarm if your kiln has an auxiliary output. This is a special-order feature. (Pg 16)

RATE Rate Calculation Type
Shows the factory setting. (Pg 16)

COST Electric Rate Enter the rate shown on your electric bill. (Pg 16)

KW The Cost to Fire Kiln
Enter your kiln's wattage. (Pg 16)

Id Computer ID Select identification number for output to a computer. (Pg 17)

TEdE Temperature Deviation
Set temperature sensitivity for FTH, FTC & LTdE errors. (Pg 17)

SFTY Maximum temp. (Pg 17)

ELEC Electronics Temp.
Check for overheating. (Pg 18)

LOCK Program Lock Make a program tamper-proof. (Pg 18)

CFG Configuration Code For technicians. (Pg 18)

SOFT Software Version
(Pg 18)

TEST Element Test Diagnostics tool. (Pg 18)

RST Reset Removes thermocouple offset and returns the board to factory defaults. (Pg 18)

Delay (pg 11)

From IdLE, press 3.
Enter time in hours:minutes. Delays the start of firing.

Add Time (pg 11)

During firing, press 2.
Each additional key press adds five minutes to a hold.

Present Status (pg 12)

During firing, press 5.
Shows the segment number that is currently firing and whether the segment is in ramp or hold.

Program Review (pg 9)

From IdLE or during firing, press 6.
Shows the program that is loaded in memory and ready to fire, or the one that is firing.

Skip Segment (pg 13)

During firing, press 9, then Enter.
Skips to the next ramp.

Firing Cost (pg 12)

Press 8 after the kiln fires to completion.
The cost of the last firing will appear. (First enter electrical cost in the **COST** option and kiln wattage in the **KW** option, pg 16.)

Multiple-Zone Options (pg 14)

DIFF Difference Largest temperature difference between any two zones. (Pg 14)

T123 Zone Temperatures
Shows temperature of each zone. (Pg 14)

Stop/Back (pg 7)

Press during firing or programming.
1) Stops a firing.
2) In Options, takes you back to **IdLE**.
3) During programming, takes you back one step each time key is pressed.

Introduction



Thank you for purchasing the Sentry micro processor, our most advanced generation of digital temperature controllers. As you read the manual, have your controller in front of you so that you can try out the keys.

The controller display messages are limited to four characters. For this reason, the messages appear cryptic: IdLE instead of “Ready to begin,” CPLT instead of “Fired successfully to completion,” RA1 instead of “Enter rate for first segment.” If at any time you are confused by these messages, turn to Appendix A: Display Messages on pages 22 - 23.

The front cover is a quick guided tour of the controller. The back cover is a quick guide to programming, to be used after you have learned the programming instructions on page 8.

Do not worry if you hear a clicking noise during operation. Mechanical relays click as they turn the heating elements on and off. This is normal.

The warranty on your Sentry controller does not cover damage from overfiring, regardless of the circumstances. It is the operator’s responsibility to make sure the kiln turns off at the end of the firing.

If you purchased the TnF 2 portable controller, you should find a TnF 2 installation instruction sheet in addition to these instructions.

Instructions for multiple-zone kilns are included in this manual on pages 13 - 14. If you are not sure whether your kiln is multiple-zone, look into the firing chamber. If you see two or three thermocouple tips, your kiln is multiple-zone. If you see only one thermocouple, skip multiple-zone instructions.

New features introduced with Sentry software version 18D: The Rate option (page 16), rate shown in Present Status (page 12), firing cost calculation (page 16), TCL alarm (page 21), PF1 alarm (page 20), and 2 segments added to the User 1 program for a total of 20 (page 7). To check the software version of your Sentry, press the OPTIONS key repeatedly until SOFT appears. Press ENTER. Your controller’s software version will appear. 18D and later versions include the new features.

Once you learn the basic features of the Sentry, you will be able to control every stage of firing. This offers learning opportunities and convenience difficult to imagine with a manual-controlled kiln.

Do not worry if you hear a clicking noise during operation. Mechanical relays click as they turn the heating elements on and off.

Do not leave the kiln unattended, especially near the expected shut-off time. Be there to make sure the kiln turns off.

©2001, by Paragon Industries, Inc. IM-218/3-10



Contents

Getting Started 5

- Room Temperature and Humidity 5
- Thunder Storms and Power Surges 5
- Time and Temperature Display . . . 5
- The IdLE Display 5
- Thermocouple Inspection 5
- Preventing an Overfire 6
- Theory of Operation 6

Programming Instructions 7

- The Stop/Back Key 7
- Correcting Entries 7
- Canceling a New Program 7
- Storing “User” Programs 7
- Firing a Stored User Program . . . 7
- Rate 7
- Hold 8
- Programming Steps 8
- Repeat Firings 9
- Program Review 9
- Programming a Cooling Segment 9
- CPLT Message 9
- Temperature Overshoot 10
- Starting a Firing in a Hot Kiln . . . 10
- AOP Fan 10
- A Practice Program 10

Sample Firing Programs 10

- Heat Treating D-2 Steel 10
- Glass Fusing Firing Schedule . . . 10
- Glass Slumping Firing Schedule 11

Other Features 11

- The Add Time Key 11
- Delay Fire 11
- Present Status 12
- The Temperature Alarm 12
- Estimating the Firing Cost 12

- Skip Segment 13
- Editing the Current Segment During Firing 13

Multiple-Zone Kilns . . . 13

- An Overview of Multiple-Zone Firing 13
- Thermocouple Failure In a Multiple-Zone Kiln 13
- Power Output Lights 13
- Testing Multiple-Zone Elements 14
- DIFF / Zone Temperature Difference 14
- T123 / Zone Temperature Display 14

The Options Key 14

- TCOS / Thermocouple Offset . . . 14
 - Calibrating Thermocouple Offset With a Digital Pyrometer 14
 - Setting Thermocouple Offset . . . 15
- Multiple-Zone Thermocouple Offset 15
- CHG- / Selecting °F or °C 15
 - °F/°C Temperature Conversion Formula 15
- TC / Thermocouple Type 15
- AOP / Auxiliary Outlet 16
- RATE / Types of Rates 16
- COST / Electric Cost Per Kilowatt-Hour 16
- KW / Kilowatts Used to Calculate Firing Cost 16
- Id / Computer ID 17
- TEdE / Temperature Deviation . . 17
- SFTY / Maximum Temperature . . 17
- ELEC / Electronics Temperature 18
- LOCK / Program Lock 18
- CFG / Configuration Code 18
- SOFT / Software Version 18
- TEST / Element Test 18
- RST / Reset 18

Error Messages 19

- FTC / Failed to Cool 19
- FTH / Failed to Heat 19
- LTdE / Low Temperature Deviation 19
- PF / Power Failure 19
- TC with Lines / Multiple-Zone Kiln Thermocouple Failure 19
- / No Thermocouple 20
- BAdP / Bad Programming 20
- ETH / Electronics Too Hot 20
- FAIL / Thermocouple Failure . . . 20
- FTL / Firing Too Long 20
- HTdE / High Temperature Deviation 20
- PF1 / Power Failure 20
- PF 2 / Power Failure 20
- PF 3 / Power Failure 20
- TC 2 / Thermocouple Failure . . . 20
- TCL / Thermocouple Lag 21
- Lld / Missing Connector Pin 21
- TCdE / Uneven Multiple-Zone Temperatures 21
- TCR / Thermocouple Leads Reversed 21
- Power Failures 21
- When the Kiln Shuts Off Too Soon 21

Appendix A: Display Messages 22

Appendix B: Upgrading Instructions 24

- Upgrading the DTC 100, 600, 800 and 1000 Series to the Sentry


Appendix C: User Program Records 26

Appendix D: Quick Programming . . . 28

Safety

The warranty on your Sentry controller does not cover damage from overfiring, regardless of the circumstances. It is the operator's responsibility to make sure the kiln turns off at the end of the firing.

Follow these safety rules in addition to the ones in your kiln or furnace manual:



- When the kiln is not in use, disconnect the power and keep the lid or door closed. (For larger kilns with heavy cordsets, we recommend a power disconnect box near the kiln.)
- Do not leave the kiln unattended, especially near the expected shut-off time. Do not leave a kiln turned on at your studio while you are at home sleeping.
- Wear firing safety glasses when looking into the peephole of a hot kiln.
- Do not touch hot sides of kiln or furnace. Keep unsupervised children away.
- Install your kiln or furnace at least 12 inches from any wall or combustible surface. (See manufacturer's recommendation for your model.)
- Do not open lid or door until kiln or furnace has cooled and all switches are off.
- Fire only in a well-ventilated, covered and protected area away from flammable materials. Keep cordset away from hot sides of kiln or furnace.
- **DANGEROUS VOLTAGE!** Do not touch heating elements with anything. Disconnect kiln or furnace before servicing.
- Do not operate if the controller itself is hotter than 158°F / 70°C. (See instructions on page 18 for checking circuit board temperature.) Never allow the firing room temperature to exceed 110°F / 43°C. (Measure room temperature three feet from the kiln.)
- Stop a firing by pressing the STOP button, not by disconnecting the power. In certain conditions, the controller will interpret a power inter-

ruption as a power failure and turn the kiln back on when you reconnect the power.

- Place the kiln on the stand recommended by the manufacturer. When a kiln is safety tested by UL, the lab fires the kiln on the stand designed for the kiln. Cinder blocks or bricks can inhibit the flow of air under the kiln. They can also change the kiln's heating characteristics.
- Place the kiln on a non-combustible surface.
- Keep the kiln lid or door closed when the kiln is not in use. This keeps dust out of the kiln. Also, should someone turn on the kiln while you are away, the closed lid will keep the heat safely inside the firing chamber.
- Never place anything on the kiln lid, even when the kiln is idle. If people become accustomed to placing papers and other objects on the kiln, they may forget and do that while the kiln is firing.
- Remove all tripping hazards from around the kiln. Keep the kiln's supply cord out of traffic areas.
- Avoid using extension cords.
- Never fire tempered glass inside a kiln. It could explode.
- Greenware, which is unfired clay, must be bone dry before firing. Moist greenware can explode inside the kiln, damaging the ware and the kiln. Place a piece of greenware against the inside of your wrist. If it feels cool, it is too wet to fire.
- Store kiln shelves in a dry area. Moist shelves can explode inside a kiln.
- If you smell burning plastic, turn the kiln off. Examine the wall outlet and supply cord for signs of burning.
- Never place extra insulation around the kiln in an attempt to conserve energy. The extra insulation can cause the wiring and the steel case to over-heat.



Chapter 1

Getting Started

Room Temperature and Humidity



It is okay to store the Sentry at sub-zero temperatures. But before operating, raise the room temperature to at least 32°F / 0°C.

Note: *The Sentry will register sub-zero °F/°C temperatures. However, 32°F / 0°C is the lowest recommended operating temperature.*

The circuit board is rated for 176°F / 80°C maximum operating temperature. However, the maximum recommended temperature is 158°F / 70°C, measured at the controller inside the kiln switch box. To lower the temperature, open windows and use a fan to blow air across the kiln's switch box louvers. (See page 18 to check circuit board temperature.)

High humidity will not adversely affect the Sentry unless water condenses on the circuit board. In this case, do not fire the kiln until the moisture has evaporated from the board.

Thunder Storms and Power Surges

Unplug the kiln when not in use, especially during thunder storms and in areas with frequent power surges. If the kiln is part way through a firing when a storm begins, it may be okay to continue the firing. When the kiln shuts off, disconnect the power.

CAUTION: *When firing the kiln during a storm, do not leave the kiln unattended!*

Time and Temperature Display

Center Dot: Time

A center dot appears during time display. It separates hours from minutes (i.e. 1 hour, 30 minutes displays as 01.30). During temperature display, the dot disappears.



Three-Light Display

The Sentry turns on the heating elements intermittently through relays. Power output lights appear in the right side of the display when the Sentry sends a signal to turn on the relays.



- **Single-Zone Kiln** When the Sentry sends a signal to the relays, all three lights appear.
- **Multiple-Zone Kiln** The top light indicates power to the top section of the kiln, the middle light power to the middle section, and the bottom light power to the bottom section. (Two-zone kilns: Ignore the center light.)

Note: *Though power output lights are on, mechanical problems can prevent the relays from turning on.*

Single Right-Hand Dot: °C

When temperature is displayed in °C, a dot appears in the lower right. In °F display, it disappears. You can choose between Fahrenheit and Celsius display. See page 15.



Operation Begins from the IdLE Display

The controller displays **IdLE** when you first apply power to the kiln. Operation begins from **IdLE**. You can't fire the kiln until **IdLE** appears.



- If you press **STOP** during a firing, **AbRT** will appear. To get back to **IdLE**, press **ENTER**.
- If the display shows an error message such as **FAIL** instead of **IdLE**, see pages 19 - 21.
- **CPLT** (firing completed) appears at the end of a firing. To make **IdLE** appear, press any key.
- If you do not touch the keys for one minute during programming, the controller will go back to **IdLE**. The controller will also discard the program you were entering and retain the previous program in memory.

Thermocouple Inspection

The small rod protruding into the firing chamber is the temperature sensor, or thermocouple.

CAUTION: *Bumping the thermocouple can push it out of the firing chamber. This could cause an overfire! The controller does not contain an alarm to detect this type of failure. Bumping the thermocouple could also cause inaccurate readings.*

Thermocouples come in different widths. The wider the thermocouple, the farther it should extend into the firing chamber. A 1/2" - 3/4" diameter thermocouple should extend into the firing chamber about 1". A 1/8" thermocouple should extend into the chamber 1/2" - 5/8". (Do not be concerned if your thermocouple extends into the firing chamber even farther.)

Keep shelves, posts and ware 1" - 1 1/2" away from the thermocouple. Keep an extra thermocouple on hand, especially if you fire hotter than 2000°F / 1093°C.

If you are using a portable, separate controller, you will need to install the thermocouple onto the kiln. See the separate TnF 2 installation instructions.

Preventing an Overfire

Even though a digital controller turns off the kiln automatically, you should monitor the kiln during firing. This is to prevent a possible overfire.

- 1 Remain nearby while the kiln is firing. Check the kiln occasionally.
- 2 Set the temperature alarm (page 12) to remind yourself to check the kiln. If you are too far away to hear the alarm, you might try using a baby monitor.
- 3 After the kiln fires to completion, disconnect the power. It is okay to turn off the power to the controller while the kiln cools to room temperature.

“Rate” is how many degrees per hour the kiln will climb in temperature. (Or how fast it cools during a controlled cooling.)

Theory of Operation

The temperature you are firing to is called the target temperature. After the Sentry reaches the target temperature, it can also hold that temperature.

The Sentry fires at a controlled heating rate. The rate is figured in degrees per hour. If you selected a rate of 100° per hour, it would take 10 hours for the furnace to reach 1000°. Rate is similar to miles per hour.

In summary, the Sentry does three basic tasks:

- 1) It fires at a controlled heating rate, or speed, measured in degrees of temperature change per hour.
- 2) It fires to a target temperature.
- 3) It can hold the target temperature.

The Sentry fires in segments, or stages. A segment is a controlled heating rate to a target temperature. A segment

can also have a hold. Shown in the chart in the left column is a segment with a target temperature of 1250°, a rate of 625°, and a hold of one hour.

The two parts of a segment:

- **Ramp:** The temperature changes.
- **Hold:** The temperature remains the same.

Heating rate is figured in degrees per hour. The recommended heating rate for the material you are firing is usually available from your supplier. It also varies depending on the thickness of the material.

A segment can have only one ramp and only one hold. Therefore, if you need more than one hold, you will have to add additional segments to the firing. Firing to a temperature at a single rate would need only one segment. Reasons to add more segments:


- To change the heating rate.
- To add a hold somewhere below the shut-off temperature.
- To control the cooling rate.

The diagram below shows a 3-segment firing. Two segments were used on the way up in temperature. Another segment was added for controlled cooling.


To figure how many hours a segment will take to fire, subtract the current temperature from the target temperature and divide the result by the heating rate. In the diagram in the left column, the firing time is $1250^\circ - 80^\circ$ (room temperature) = $1170 \div 625 = 1.87$ hours.

After the Sentry has finished firing the last segment, it will turn off power to the heating elements.

Parts of a Segment



This segment will reach the target temperature of 1250° in 2 hours, then hold that temperature for 1 hour.



Here is a simple 3-segment program. Segments 1 and 2 each have a hold. Segment 3 is a controlled cooling segment.

Chapter 2

Programming Instructions

Before using your Sentry, read all of this chapter. Have your controller in front of you so that you can try out the keys as you read.

The Stop/Back Key

You can stop a firing at any time by pressing **STOP**.

If you enter Options, you do not have to go through all the prompts to get back out. Press **STOP** to go to **IdLE**.

During programming, the **STOP/BACK** key will take you back one programming step with each key press, so it is easy to make corrections.

Correcting Entries

If you enter the wrong temperature, rate, etc., while programming, enter 0000. Then enter the correct numbers before pressing **ENTER**.

Canceling a New Program

If you do not touch the keys for one minute during programming, the controller will go back to the **IdLE** display. The controller will also discard the program you were entering and will retain the previous program in memory.

This is useful if you change your mind during programming and decide to keep the previous program. Instead of completing the new program, wait a minute and let the controller return to **IdLE**.

Storing “User” Programs

To program the controller, **IdLE** must appear. From **IdLE** press **4**. **USER** will appear. The controller is ready for you to choose a stored program or to enter a new one. (See next page for programming instructions.)

The controller can hold 9 programs in memory. They stay in memory even when the power is turned off. Stored programs are numbered 1 through 9. User program 1 can have up to 20 segments. User programs 2 - 9 can have 10 segments each. You don't have to use all the segments

When USER appears, the controller is asking you to select a stored program. If you have none in memory, press 1 and enter your first program.

available—use only the number needed. Often one segment is all you will need.

When you program a firing, you will be asked to enter a rate for each segment. Step 7, Programming Instructions, next page, shows you how to zero out the segments you don't need.

When entering a program for the first time, press **1** after **USER** appears. Your first firing will be stored as Program 1.

Each time you store another program, select the next available number, such as 2, at the **USER** prompt. Selecting a number for a new program over-writes (erases) any program stored there. Write down your user programs for quick reference. (Make copies of the blank form on page 26.)

Note: For repeat firings that you don't want to inadvertently change, see Program Lock, page 18.

Firing a Stored User Program

After you enter a new program and the display shows **IdLE**, the new program is in memory and ready to fire.

Selecting a different stored program takes only seconds:

- 1 From **IdLE** press **4**.
- 2 **USER** will appear. Enter the program number (1 - 9).
- 3 If there are no changes to the program, press **STOP** twice. **IdLE** will appear. The controller is ready to fire your selected program. To begin firing, press **ENTER** once.

Note: Use Program Review, page 9, before firing. See also “Repeat Firings,” page 9.


Keep a record of your stored programs and all your firings. Write down the results of each firing. This may become invaluable later.

Rate

Each segment must include a rate, which is the firing speed of that segment. We measure rate as degrees per hour. This is similar to miles per hour; just replace miles with degrees. During programming, enter the rate when **rA** appears. (**rA** will also include the segment number: **rA 1** **rA 2** etc.)

The diagram on the next page shows three rates. A rate of 1000° per hour will reach 1000° in 1 hour. A rate of 500° will reach 1000° in 2 hours. A rate of 333° will reach 1000° in 3 hours.

If you want the furnace to fire at full speed, enter a rate of 9999. See Programming Steps, step 3, next page.



Note: In Program Review, a heating rate of 9999 is displayed as **FULL**. When a kiln is heated at full power, it may overshoot the target temperature, especially in the lower range. To avoid this, add an extra segment with a slower rate for the last 50 degrees of temperature rise.

CAUTION: The Sentry includes error messages to warn you when the kiln is at the wrong temperature. Firing the kiln at full rate turns off some of these warnings. See *TEdE Temperature Deviation*, page 17, and *HTdE High Temperature Deviation*, page 20.

If you are not sure how fast to fire, remember an old firing adage: When in doubt, slow it down.

Note: At the time that you purchase the controller, the factory can set up your controller to calculate rate in one of three ways: 1) degrees of temperature change per hour 2) degrees of temperature change per minute, or 3) elapsed time needed to reach a temperature. The normal setting is degrees per hour. If you are having problems entering rate, check the **RATE** option to be sure your controller is set for degrees per hour, page 16. (This note applies only to 18D and later software versions. All pre-18D controllers figure rate only as degrees per hour. See page 18, **SOFT** option, to look up software version.)

Hold

Hold is the length of time that you want the kiln to remain at the target temperature. Hold is also called soak or dwell time. Hold gives the temperature time to become more even throughout the kiln. Hold can be used in either heating-up or cooling-down segments.

In programming step 5 (see next column), enter hold time. When hold is set to 99.99 hours, the Sentry will remain at that temperature indefinitely until you press **STOP**.

When the Sentry is in hold during a firing, the display will alternate between time left in hold and the temperature.

Programming Steps

Use these instructions for your first firings. Later you may prefer “Ramp-Hold Shorthand Instructions,” back cover.

As you follow these steps, you will see values (temperatures, rates, etc.) from the last firing. To use these again, press **ENTER**. To program a controlled cooling, set the segment to a lower target temperature than that of the preceding segment.

To fire without Alarm or Delay: Follow steps 1 through 7. Then press **START** once.

- 1 Apply power to the kiln. **8888** then **IdLE** will appear. (Press **ENTER** if **IdLE** does not appear.)
- 2 Press **4**. **USER** will appear. Enter a program number from 1 to 9.
- 3 Press **ENTER**. **rA 1** will appear. Enter firing rate for segment 1 (temperature change per hour: from 1° to 9999°).
- 4 Press **ENTER**. **°F 1** (or **°C 1**) will appear. Enter the target temperature of segment 1.
- 5 Press **ENTER**. **Hd 1** will appear. Enter segment 1 hold time in hours / minutes (e.g. 12 hours, 30 minutes = 12.30). No hold = 00.00.
- 6 Press **ENTER**. If **FN 1** appears, and you have an AOP receptacle on your kiln, use the 1 or 2 key to select ON or OFF. Press **ENTER**. (For more details on AOP, see page 16.)
- 7 Continue entering values for the segments needed. When **RA** appears for the first segment you don't need, press **0**, then **ENTER**. **IdLE** will appear. The kiln is ready to fire.
- 8 **To set Alarm:** press **7**. **ALAR** will appear. Enter alarm temperature. (Enter **0** to turn alarm off.) Then press **ENTER**. **IdLE** will appear.
- 9 **To set Delay:** press **3**. **dELA** will appear. Enter delay time (i.e. 12 hours, 30 minutes = 12.30). Then press **ENTER**. **IdLE** will appear. (Delay zeroes out after each completed firing.)
- 10 **To start program:** From **IdLE** press **ENTER** once. **STRT** will appear, then kiln temperature. If a delay was programmed, **DELA** will appear, then time remaining until start. To stop the firing at any time, press **STOP**.

We recommend using Program Review (page 9) before firing. When program fires to completion, **CPLT** will appear. Press **ENTER**. **IdLE** will appear.

Repeat Firings

To repeat the last firing, press **ENTER** from **IdLE**. The kiln will begin firing. Make sure you are repeating the correct firing by using Program Review (next page). For repeat firings that you don't want to inadvertently change, see Program Lock, page 18.

If you repeat the same firing program often, use Program Lock so that it cannot be inadvertently changed. See page 18.

It is easy to program a controlled cooling. Simply enter a target temperature that is lower than that of the previous segment.

Program Review

When you press **ENTER** to begin firing, the controller will fire the program that is in active memory. Program Review shows the values for that program. The program in active memory is—

- The program that was fired last, or
- The program that was selected since the last firing.

Start Program Review from **IdLE**, or while firing, by pressing **6**.

Programming a Cooling Segment

For controlled cooling, program a segment to a lower target temperature than that of the preceding segment.

Example: You fire at a rate of 500°F per hour to 1450°F with your first segment. Then you want the kiln to cool at a rate of 100°F per hour down to 700°F. Here is how you would program the two segments:

Segment	Rate °F/°C	Temp. °F/°C	Hold
1	500 / 277	1450 / 788	00.00
2	100 / 55	700 / 371	00.00

The first segment is the heating segment. The second one is the cooling segment. The controller does not use minus numbers for cooling. Just enter a lower target temperature than that of the previous segment.

If you prop the lid or door for a fast cooling, program a fast cooling rate for that segment. If you lower the temperature quickly by propping the lid but program a slow cooling rate, the controller will just raise the temperature again.

Example: Some glass artists flash-cool the glass just after it fuses. They open the door a few inches to remove

CPLT means the kiln has fired to completion and the heating elements are turned off. To make IdLE appear, press any key.

heat, then close it again. This takes the glass down rapidly through the devitrification range. To program a flash-cool, use a rate of 9999. This shuts off the heating elements during that segment, allowing the kiln to cool rapidly.

Note: During fast cooling, do not open the door all the way. Do not force-cool the kiln with a fan.

Note: See Temperature Deviation (TEdE), page 17, for information on error codes that may appear during “crash” cooling. To turn these codes off, program a crash cooling rate of 9999. This turns off TEdE error codes only for that particular segment. The TEdE codes still work on the hold and the other segments.

Suppose you enter a cooling rate that is faster than the kiln can cool? Depending on the rate you enter, you may get an alarm message. (Press **ENTER** to turn off the alarm.) **The controller, of course, cannot speed cooling beyond the kiln's natural cooling rate.**

CPLT Message: Firing Completed

When the firing has successfully completed, the Sentry will shut off power to the elements. Then four messages will cycle one after the other:

- 1 **CPLT** (complete)
- 2 Firing time in hours and minutes
- 3 The temperature reached during the last segment
- 4 The current kiln temperature

Note: After the kiln fires to completion, disconnect the power. It is okay to turn off the power to the controller while the kiln cools to room temperature.

Note: Pre-18D software version controllers: (See page 18 to find software version) If **CPLT** appears immediately after you press **START**, it is because all programmed temperatures are lower than the current kiln temperature. If the alarm sounds (see page 12), and then the kiln fires to completion, you will see **ALAR** instead of **CPLT**. Press **ENTER**. **CPLT** will appear.

Temperature Overshoot

When a kiln is heated too fast, it may overshoot the target temperature, especially in small kilns at lower temperatures. To avoid this, add an extra segment to slow the firing. The segment with the slower rate should begin approximately 40° - 60° below the final target temperature.

Starting a Firing in a Hot Kiln

Sometimes a firing begins in a hot kiln after a power failure or other interruption. In this case, the Sentry will begin firing from the first segment that matches the current temperature. See Power Failures, page 21.

AOP Fan

The optional AOP (auxiliary output) is a special-order electric receptacle mounted in the kiln's switch box. This receptacle can power a kiln vent or external alarm. (See Options, page 16.) During programming, **FN** will appear for each segment (**FN 1 FN 2 FN 3** etc.). Use the 1 and 2 keys to select On or Off for each segment. **FN** will appear only if the AOP has been activated in the AOP Option.

A Practice Program

Seg	Rate	Temp	Hold
1	250	750	—
2	900	1425	.30
3	150	750	—

To practice using the controller, we will enter a program that includes three segments. The last segment is a cooling segment.

Using the programming instructions on page 8, enter this firing schedule. Then use Program Review to check for accuracy.

USER = 1
RA1 = 250
°F 1 = 750
Hd 1 = 00.00
RA2 = 900
°F 2 = 1425
Hd 2 = 00.30
RA3 = 150
°F 3 = 750
Hd 3 = 00.00
RA4 = 0

If you fire at a very rapid rate, the kiln may momentarily overshoot the programmed target temperature. To avoid that, use a slower rate.

Note: Enter 0 for the rate in segment 4. This zeroes out all the segments past segment 3.

Chapter 3

Sample Firing Programs

These sample firing schedules illustrate different ways to program the Sentry. When designing a firing schedule for materials you are unfamiliar with, or when using one of these schedules, always test-fire samples first. This is because these generalized schedules may not exactly suit the materials that you fire in your kiln.

For practice, you might want to enter these programs even though you may never actually use them.

Heat Treating a Knife Made from D-2 High Carbon Steel

Segment	Rate °F / °C	Temp. °F / °C	Hold
1	9999	1800 / 982	00.20
2	9999	400 / 204	00.00
3	500	500 / 260	5.00

Wrap the knife blade in heat treating foil. (The foil prevents carbon scale from forming on the steel.)

Set the alarm to 1800°F / 982°C. Place the knife in the kiln. Heat at FULL rate to 1800°F / 982°C. When the alarm sounds, get ready to remove the knife. After 20 minutes of hold time, open the furnace door, remove the knife, and leave the door half open.

CAUTION: *Wear high temperature heat-resistant gloves when removing the knife blade from the furnace.*

Remove the blade from the heat treating foil. Place the knife on knifeholders, which allow air to circulate around the blade. Place a fan several feet from the blade. Point the blade toward the fan so the air flows parallel to the blade length. Cool the blade rapidly to room temperature.

CAUTION: *If the air hits the blades sideways, the chance of warpage increases.*

Leave the kiln door half open until the temperature drops to 400°F / 204°C. Place the knife back inside the furnace. Segment 3 will heat the kiln to 500°F / 260°C. Leave the knife in the kiln for 2 hours. Remove the knife. Let it cool to room temperature. Place it back inside the kiln for another 2 hours. Then remove the knife.

Glass Fusing Firing Schedule

Segment	Rate °F / °C	Temp. °F / °C	Hold
1	250 / 138	750 / 398	00.00
2	900 / 500	1425 / 773	00.30
3	9999 / 9999	1050 / 565	00.00
4	150 / 83	750 / 398	00.00

Stained glass, 1/8", 2 layers, full fuse. The fusing temperature will vary depending on the brand of glass, the batch, and even on the color. Vent the lid. Set the alarm to 500°F. When the alarm sounds, close the lid from venting position and insert peephole plugs.

Set the alarm again, this time to 1350°F. When it sounds, check the glass through the peephole. When the glass fuses to your satisfaction, write down the temperature and hold time for future firings, and press **9**, then **ENTER** (Skip Segment).

This will advance the kiln to segment 3, a flash cooling segment. Lift the kiln lid slightly or open the door ajar until the temperature drops to 1050° F. Then close the door / lid. The kiln will cool slowly through the annealing range, then turn off.

Note: A cooling rate of 9999 (FULL) shuts off the warning alarm (error message) that sometimes sounds during rapid cooling. This turns off the alarm only for that particular ramp. The alarm codes still work on the hold and the other programmed segments. For details about error messages, see pages 19 - 21.

Glass Slumping Firing Schedule

Segment	Rate °F / °C	Temp. °F / °C	Hold
1	250 / 138	750 / 398	00.00
2	900 / 500	1250 / 676	00.30
3	9999 / 9999	1050 / 565	00.00
4	150 / 83	750 / 398	00.00

Stained glass, 1/8", 2 fused layers, 12" circular pieces, slumped into a bowl. Set the alarm to 500° F. When the alarm sounds, close the lid from venting position and insert peephole plugs.

Set the alarm again, this time to 1150° F. When it sounds, check the glass through the peephole. When the glass slumps into the bowl, write down the temperature and hold time for future firings, and press **9**, then **ENTER** (Skip Segment).

This will advance the kiln to segment 3, a flash cooling segment. Lift the kiln lid slightly or open the door ajar until the temperature drops to 1050° F. Then close the door/lid. The kiln will cool slowly through the annealing range. Then it will turn off and cool to room temperature.

Note: A cooling rate of 9999 (FULL) shuts off the warning alarm (error message) that sometimes sounds during rapid cooling. This turns off the alarm only for that particular ramp. The alarm codes still work on the hold and the other programmed segments. For details about error messages, see pages 19 - 21.

Chapter 4 Other Features

The Add Time Key

2
ADD TIME

This key adds 5 minutes to a hold. It is designed for ceramists who watch witness cones and for glass artists who inspect the glass near the end of firing.

- 1 During a firing, press **2**. **HOLD**, and time in hold, will appear.
- 2 Press **2** again. The time shown will increase by 5 minutes.
- 3 To return to the temperature display, press **START** or wait 1 minute.

Note: Add Time will add 5 minutes to hold even if no hold had been programmed. After hold time displays, 5 minutes are added with each press of the key.

With the Add Time button, you can add time to a hold. With the editing feature, you can change both target temperature and hold.

Delay Fire

3
DELAY

This delays the start of the firing by the amount of time entered. Use it to fit a firing into your schedule or to take advantage of lower electric rates at night. Delay zeroes out after each firing. Therefore, it must be programmed again for each firing. The maximum delay is 99 hours and 59 minutes.

- 1 First, enter the program you are going to fire.
- 2 From **IdLE** press **3**. Enter delay time (i.e., 5 1/2 hours = 05.30). Press **ENTER**.
- 3 To begin Delay, press **ENTER** once from **IdLE**. A Delay count-down timer will appear.

Note: Press **START** during delay to end the delay and begin the firing. (You could also press **STOP** to end the delay and then **START** to begin the firing.)

CAUTION: For safety, do not leave the kiln alone during a delay or a firing. We cannot guarantee your kiln against overfiring even though the controller is automatic. The operator assumes full responsibility for shutting the kiln off at the proper time.

Present Status

5
PRESENT STATUS

Press **5** during a firing to display the segment that is firing. One of the following messages will appear:

- **RA** , the segment number, and rate: The Sentry is in the ramp part of a segment. (See charts, page 6.)
- **Hd** and segment number: The Sentry is in the hold part of a segment.

The controller returns to normal display after 5 seconds.

Note: *Present Status shows the actual firing rate of the current segment instead of the rate you programmed. If you think your kiln is heating or cooling too slowly, compare the rate shown in Present Status with the rate you programmed for that segment. This is another reason you should always keep a written record of your firing programs.*

Note: *Pre-18D software versions show the programmed rate in Present Status. Software version 18D and later controllers show the rate actually achieved instead of the rate you programmed. (See page 18, **SOFT** option, to look up software version.)*

Present Status is useful when firing a program that contains heating and cooling segments. Without Present Status, it might be easy to lose track of which segment is firing.

The Temperature Alarm

The alarm sounds and **ALAR** flashes when the kiln reaches the alarm temperature that you enter. Use the alarm to alert you to check the fusing or slumping of glass or to remove a knife blade from the furnace at the end of heat treating.

You can enter only one alarm temperature at a time. However, after the alarm beeps, you can set the alarm for another temperature, as many times as you want, during the firing. Entering an alarm temperature automatically erases the previous alarm temperature.

Note: *The alarm temperature that you set during a firing must be higher than the current display temperature. The alarm is designed only for higher temperatures and not for cooling temperatures.*

After the alarm beeps, the alarm temperature will stay in memory for future firings until you replace it with a new temperature.

Use the alarm to remind yourself that the kiln is getting close to the shut-off temperature. Always check the kiln before it shuts off.

7
ALARM

Monitoring the Alarm from a Distance

Place an inexpensive baby monitor near the kiln. From another location in your building, you will be able to hear the temperature alarm beeping and the the relays clicking.

Setting the Alarm From Idle

- 1 From **IdLE**, press **7**. **ALAR** will appear alternating with the last alarm temperature entered.
- 2 Enter alarm temperature. Press **ENTER**. **IdLE** will appear. (If you do not want to use the alarm, set the alarm temperature to **0**. This setting will disable the alarm.)

Note: *Your controller's maximum temperature is shown in the **SFTY** option (page 17). If you enter an alarm temperature that is higher than the maximum temperature, the alarm temperature will automatically change to the controller's maximum temperature.*

When the alarm sounds, shut it off by pressing any key except **STOP**. (Pressing **STOP** while an alarm sounds will shut off the kiln.)

Note: *If the alarm sounds as soon as firing begins, it is because the alarm was set to a temperature below the current temperature.*

Setting the Alarm During Firing

- 1 The alarm beeps while the kiln is firing. Press **7**.
- 2 Enter the new temperature.
- 3 Press **ENTER**. The kiln will continue firing.

If you touch **7**, enter a new temperature, and forget to press **ENTER**, the controller will merely continue firing without resetting the alarm.

Estimating the Firing Cost

8
FIRING COST

Note: *This feature is included with software version 18D and newer controllers. To look up your software version, see page 18.*

The Sentry controller can figure the electrical cost of a firing. Set up the controller as follows:

In the **COST** option, enter the cost of a kilowatt-hour of electricity. See page 16.

In the **KW** option, enter the wattage for your kiln. See page 16.

After the kiln fires to completion, **CPLt** will flash. Press the **8** key. The cost of electricity to fire the last load will appear. To return to temperature display, press **ENTER**.

Note: *If you enter the kiln wattage in the **KW** option but you do not enter cost per kilowatt-hour in the **COST** option, the controller will display kilowatt-hours instead of firing cost.*

Skip Segment

Skip Segment works only during firing. It jumps the firing from the current segment to the next one.

Note: *Skip Segment does not skip from a ramp to a hold. It skips to the next segment.*

To skip a segment, press **9**. **SKIP** will appear, then the current segment. Press **ENTER**. (If you change your mind and don't want to skip that segment, don't press **ENTER** after **SKIP** appears. Instead, press **9** again. The firing will continue in the same segment.)

Skip Segment skips to the ramp of the next segment from either a ramp or hold of the current segment.

Skip Segment Example

For more examples, see Chapter 3.

- **Skipping to a Cooling Segment:** You have programmed 1425°F for glass fusing, followed by a segment for controlled cooling. Watching the glass through the peephole, you notice that the glass edges have rounded nicely at 1315°. Use Skip Segment to end the firing segment and begin the one for slow cooling.

Note: *Make a note of the temperature at which the glass fused. Program that temperature for the next firing of that type of glass.*

Editing the Current Segment During Firing

While the kiln is firing, you can change the target temperature and hold time of the current segment. (You can edit only the segment that is firing. To edit other segments, wait until the firing has progressed to those segments.)

Even if the current segment has already started its hold time, you can still edit the segment's target temperature. You can raise or lower the target temperature. The controller will go back out of hold and fire to the new target temperature at the original rate. (You cannot edit the rate, however.)

- 1 During firing, press **4**.
- 2 The display will show the target temperature of the current segment. Use the number keys to change the temperature. Then press **ENTER**.
- 3 The display will then show the hold time (or 00.00 if there is no hold time) of the current segment. Change the time, if needed, and press **ENTER**. The kiln will resume firing.

9
SKIP
SEGMENT

4
PROGRAM

Chapter 5

Multiple-Zone Kilns

An Overview of Multiple-Zone Firing

Look into the firing chamber. The number of thermocouple tips indicates the number of zones.

If you are not sure how many zones your kiln has, look into the firing chamber. The number of thermocouple tips indicates the number of zones.

In single-zone kilns, the Sentry measures temperature from one location. When the controller turns on the heat, all the elements turn on.

With two- and three-zone kilns, the Sentry measures temperature from each individual zone. It then adjusts the heat separately for each zone to improve temperature uniformity.

To maintain even temperature, the Sentry calculates not only temperature difference between zones, but also length of time needed to change temperature. By carefully timing heat output, it maintains even temperature with a minimal loss in firing speed.

Note: *Multiple-zone kilns use the same programming instructions as single-zone kilns.*

Note: *Firing a Ramp-Hold program at FULL rate (9999) shuts off multiple-zone control for that firing. The kiln then fires as a single-zone kiln.*

Thermocouple Failure In a Multiple-Zone Kiln

In a multiple-zone kiln, if a thermocouple fails, the firing will continue as a single-zone kiln so long as one thermocouple still operates. **FAIL** will appear, alternating with the thermocouple that failed. (See page 19 for multiple-zone thermocouple error messages.)

Power Output Lights

The three lights on the right of the temperature display turn on when the controller sends a signal to the relays.

- **Single-Zone Kiln** When the Sentry sends a signal to the relays, all three lights appear.
- **Multiple-Zone Kiln** The top light indicates power to the top section of the kiln, the middle light power to the

middle section, and the bottom light power to the bottom section. (Two-zone kilns: Ignore the center light.)

Note: *Though power output lights are on, mechanical problems can prevent the relays from turning on.*

- When a zone temperature is too low, its indicator light will flash rapidly. The heating elements in that zone will stay on continuously, and the controller will attempt to balance the heat in the other two zones.

Testing Multiple-Zone Elements

When relays or thermocouples are connected to the wrong controller terminals, zones will show a wide temperature difference. To wire the kiln properly, trace the switch box wiring with the kiln's wiring diagram. Also, see "Element Test," page 18.

Multiple-Zone Options

These options appear only on multiple-zone kilns. They are accessed by pressing the Options key.

DIFF / Zone Temperature Difference

View Maximum Temperature Spread

For a two-zone kiln, this option shows temperature difference between the zones. For a three-zone kiln, it shows the highest temperature difference between any two zones. If the temperature shown is larger than expected, go to option T123 to view the temperature of each zone.

- 1 Press **OPTIONS** repeatedly until **DIFF** appears. Press **ENTER**.
- 2 The maximum difference in temperature between any zones will display. (Example: **-003** = 3°)

T123 / Zone Temperature Display

View Temperature of Each Zone

- 1 Press **OPTIONS** repeatedly until **T123** appears. Press **ENTER**.



- 2 The temperature for each zone will display one after the other, cycling for one minute. Then normal temperature display will return. For example:

- Top zone: **TC 1** | **1250**
- Middle zone: **TC 2** | **1251**
- Bottom zone: **TC 3** | **1249**

Chapter 6

The Options Key

The Options key gives you access to a list of special features. With each press of the Options key, you will see the display code for the next option.

- 1 When you find the option you want to use, press **ENTER**.
- 2 Use the **1** and **2** keys to select changes within the option.
- 3 After making a selection for an option, press **ENTER**. The display code for the option you just changed will appear. You are then ready to go to the next option.

Note: *If you select a change for an option but don't press **ENTER**, the change will not go into effect.*

There are two ways to get out of Options and back to

IdLE:

- 1 Press **STOP**.
- 2 Do nothing for 60 seconds in Options. You will automatically be taken out of the Options display and back to **IdLE**.

Note: *If you are firing the kiln while in Options, pressing **STOP** takes you out of Options and back to the firing display. But it does not stop the firing.*

TCOS / Thermocouple Offset

Calibrate the Thermocouple(s)

The thermocouple is the rod protruding into the firing chamber. It measures temperature. Thermocouples can "drift" as they age, causing a shift in temperature readings. Thermocouple Offset calibrates the controller to compensate for drift.

Note: *The thermocouple must protrude into the firing chamber the correct distance: 1" for 1/2" - 1/4"-wide thermocouples, 1/2" for 5/8" - 1/8"-wide thermocouples.*

Calibrating Thermocouple Offset With a Digital Pyrometer

You can calibrate Thermocouple Offset using a calibrated digital pyrometer. One way to calibrate your pyrometer is to take it to a heat treater or other location that has a calibrated controller you can trust. Take a reading from a furnace with your pyrometer. Either zero it out to match the calibrated controller on the furnace, or write down the temperature difference between your pyrometer and the reliable source. Store your pyrometer. Use it only for cali-

brating controllers. Thus, it remains a reliable calibration standard.

Note: *The temperature at which you calibrated your digital pyrometer should be the same temperature you use to check the controller's temperature readout. Example: If you took a reading from a reliable source at 2000°F, you should check your controller reading at around 2000°F.*

Mount the thermocouple of the calibrated pyrometer in the firing chamber near the Sentry's thermocouple. With the Sentry on hold, compare readings between the Sentry and the calibrated pyrometer. Adjust Thermocouple Offset to compensate for any temperature difference between them.

Note: *You can also return your controller to the factory to have it calibrated on certified test equipment.*

Setting Thermocouple Offset

You can enter a temperature change up to 45°F / 25°C higher or lower than the zero factory setting.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **TCOS** appears.
- 2 Press **ENTER**. **C 0**, or a thermocouple offset number, will appear.
- 3 Using the **1** and **2** keys, enter the new offset. (See chart below.) Press **ENTER**. **TCOS** will appear. To return to **IdLE**, press **STOP**.

Thermocouple Offset Settings

°F Setting	°C Setting	Result
C 0	C 0	No adjustment
H 1-45	H 1-25	Kiln will fire hotter
C 1-45	C 1-25	Kiln will fire cooler

Thermocouple Offset Examples

Setting	Result
H 1	Kiln will fire 1° hotter
H 17	Kiln will fire 17° hotter
C 12	Kiln will fire 12° cooler

Multiple-Zone Thermocouple Offset

- 1 From **IdLE**, press **OPTIONS** repeatedly until **TCOS** appears.
- 2 Press **ENTER**. **TC1** (top thermocouple) will appear.
- 3 While **TC1** displays, press **OPTIONS**. The other thermocouple(s), then **TCOS**, will appear with each press of the **OPTIONS** key:
 Three-zone kilns: **TC1 TC2 - TC3 TCOS**
 Two-zone kilns: **TC 1 TC3 TCOS**
- 4 When the correct thermocouple appears, press **ENTER**.
- 5 Using the **1** and **2** keys, enter the new offset. (See charts above.) Press **ENTER**. The thermocouple you

adjusted (i.e. **TC**) will appear. Select another thermocouple by pressing **OPTIONS** or return to **IdLE** by pressing **STOP**.

CHG- / Selecting °F or °C

The controller operates in your choice of Fahrenheit or Celsius temperature. In °C display, a lighted dot appears in the lower right. In °F, it disappears. To switch from °F to °C or vice versa:

- 1 From **IdLE**, press **OPTIONS** repeatedly until **CHG-** appears.
- 2 Press **ENTER**. Use the **1** and **2** keys to select **°F** or **°C**.
- 3 After selecting one of the above, press **ENTER**. Press **STOP** to return to **IdLE**.

°F/°C Temperature Conversion Formula

Below are formulas for converting temperature between °F and °C. Converting a firing rate requires a different formula than converting a firing temperature:

Firing Temperature

(Example: "Fire to 1600°F." 1600°F = 871°C)

$$(\text{°C} \times 1.8) + 32 = \text{°F}$$

$$(\text{°F} - 32) \div 1.8 = \text{°C}$$

Firing Rate and Temperature Change

(Example: "Fire at 200°F per hour" or "Fire 200°F hotter." 200°F = 111°C)


$$\text{°C} \times 1.8 = \text{°F}$$

$$\text{°F} \div 1.8 = \text{°C}$$

TC / Thermocouple Type

Select Type-K, -S or -R Thermocouple

The Sentry can use Type-K, -S or -R thermocouples. If you specialize in firings above 2200°F / 1204°C, you should use the Type-S or -R. Type-K is best suited for temperatures below 2200°F / 1204°C.



The S-Type thermocouple has a ceramic sheath. Most K-Type thermocouples have a metal sheath.

The controller cannot detect the type of thermocouple installed in your kiln. So if you change the thermocouple to a different type, be sure to select the new thermocouple type in TC option.

Note: *Ask your kiln supplier if you are not sure about the type of thermocouple in your kiln.*

CAUTION: Be careful about changing the thermocouple type! *If you select Type-S or -R, but your kiln is wired with a Type-K, your kiln will underfire. If you select Type-K and your kiln is wired with a Type-S or -R, your kiln will OVERFIRE. After*

using the Reset (RST) option (page 18), use the TC option to select the correct thermocouple. Reset changes the thermocouple selection to Type-S.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **TC** appears.
- 2 Press **ENTER**. Use the **1** and **2** keys to select **TC K**, **TC R** or **TC S**.
- 3 After selecting one of the above, press **ENTER**. Press **STOP** to return to **IdLE**.

AOP1, AOP2 /Auxiliary Outlets

Select Vent Fan or Alarm for the Auxiliary Outputs

The optional AOP1 and AOP2 (Auxiliary Outputs) are for electrical receptacles mounted in the kiln's switch box. The outlets can each power a kiln vent or an external alarm, such as a bell. (The AOP outlet is a special-order option that might not be included on your kiln.)

The choices in the AOP1 and AOP2 options:

- **ALRM Alarm:** This choice sends power to the AOP receptacle whenever the alarm sounds. (See Temperature Alarm, page 12.) Plug in a loud bell to alert you, from a distance, that the kiln has reached the alarm temperature. (Controllers with pre-20A software: Select **F2A3**.)
- **NONE None:** Use this setting if your kiln does not have the AOP outlet.
- **VFAN Kiln Vent or Gas Outlet:** This option adds a prompt for fan (**FN**) to each segment during programming (page 8). (Controllers with pre-20A software: Select **A2F3** or **FAN3**—whichever appears.)
 - 1 From **IdLE**, press **OPTIONS** repeatedly until **AOP1** or **AOP2** appears.
 - 2 Press **ENTER**. Use the **1** and **2** keys to select **VFAN ALRM** or **NONE**.
 - 3 After selecting one of the above, press **ENTER**. Press **STOP** to return to **IdLE**.

RATE / Types of Rates

Note: This feature is included on controllers with software version 18D or newer. To look up your software version, see the SOFT option, page 18.

The standard method of programming firing rate is degrees of temperature change per HOUR. At the factory, we can set up your controller to calculate rate instead as degrees of temperature change per MINUTE, or as ELAPSED TIME needed to reach a temperature. The RATE option shows you which method your controller uses:

- 1 From **IdLE**, press **OPTIONS** repeatedly until **RATE** appears.
- 2 Press **ENTER**. You will see one of the following:

HOUR (Degrees of temperature change per hour)

MIN (Degrees of temperature change per minute)

TIME (Elapsed time needed to reach a temperature)

Only the factory can change the type of rate used in your controller.

Note: If your controller uses TIME rate, enter the hours/minutes that each segment will take to reach its target temperature. (Example: 1 hour, 30 minutes = 01.30.)

COST / Electric Cost Per Kilowatt-Hour

Note: This feature is included on controllers with software version 18D or newer. To look up your software version, see the SOFT option, page 18.

The controller can figure the cost of a firing if you enter the cost of electricity for your area (and kiln wattage—see next option). The cost of electricity is figured in kilowatt-hours (KWh). A kilowatt-hour is 1,000 watts of electricity running for 1 hour. (10 – 100-watt light bulbs glowing for one hour consume 1 KWh of electricity.)

To find what the power company charges you for a kilowatt-hour, look at your electric bill, call your power company, or visit their website. The electric rate may vary depending on the time of year and amount of electricity you use. In the summer, rates in some areas are higher. Also, add the other costs listed on your electric bill, such as power transmission charges, taxes, etc.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **COST** appears. Press **ENTER**.
- 2 From an electric bill, enter the cost of a kilowatt-hour. Place cents to the right of the decimal. Round off fractions. (Example: Enter 9.25 cents per kilowatt-hour as 00.09.) Press **ENTER**.
- 3 Press **STOP** to return to **IdLE**.

Note: You can enter the cost in U. S., Canadian, or Euro cents, British pence, Indian paisas, or any other money system that is based upon 100 units (i.e. 100 cents = 1 dollar.) If your system is based upon 1000 units, such as the Libyan dirham, the Oman baiza, or the Kuwait fil, divide the cost by 10. Example: Enter 140 as 00.14. Then multiply by 10 the cost of a firing shown in the controller display.

KW / Kilowatts Used to Calculate Firing Cost

Note: This feature is included on controllers with software version 18D or newer. To look up your software version, see the SOFT option, page 18.

To figure the cost to fire your kiln, the controller needs to know how many kilowatts your kiln uses. Look at your

kiln's electrical data plate. It is usually on the side of the switch box. The data plate lists the watts, amps, and volts. If watts are not listed, multiply amps x volts. (Example: 15 amps x 240 volts = 3,600 watts.)

Divide the wattage of your kiln by 1000, which gives the kilowatts. (Move the decimal point 3 spaces to the left.)

Examples:

$$10,800 \text{ watts} \div 1000 = 010.8$$

$$4,800 \text{ watts} \div 1000 = 004.8$$

$$800 \text{ watts} \div 1000 = 000.8$$

Enter that amount in the KW option:

- 1 From **IdLE**, press **OPTIONS** repeatedly until **KW** appears. Press **ENTER**.
- 2 The controller shows 4 digits for entering kilowatts: **000.0**. Enter kilowatts for your kiln.
- 3 Press **ENTER**.
- 4 Press **STOP** to return to **IdLE**.

Note: Please do not confuse kilowatts with kilowatt-hours. A kilowatt is 1,000 watts. A kilowatt-hour is 1,000 watts powered for one hour.

To view the cost of a firing, press the **8** key after the kiln has fired to completion and **CPLT** flashes.

Id / Computer ID

Enter an ID Number for Connection to a Computer

This feature is for assigning an identification number, from 1 to 15, to the controller. It is used only for hookup to a personal computer, which requires an optional kit.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **Id** appears.
- 2 Press **ENTER**. Use the **1** and **2** keys to select an ID number from 1 to 15. Press **ENTER**. Press **STOP** to return to **IdLE**.

TEdE / Temperature Deviation

Adjust Temperature Sensitivity of Error Codes

The temperature that the controller is trying to reach, at any given time, is called the set point. During heating or cooling, the set point changes at the rate you programmed. During a hold, the set point remains steady.

The Sentry shows error messages when it can't maintain the set point temperature. The cushion, or leeway, allowed before an error message flashes is called Temperature Deviation. When the temperature is off target by more than the Temperature Deviation setting, the alarm sounds. Temperature Deviation affects these error messages (see page 19):

FTH Fail to Heat

FTC Fail to Cool

LTdE Low Temperature Deviation

Note: On controllers that have pre-18D software, the **TEdE** setting also affects the **HTdE** High Temperature Deviation alarm (page 20). On 18D and later controllers, the **HTdE** setting is always 100°F / 56°C.

Some people worry when **FTH**, **FTC** or **LTdE** appears. They wonder if something is wrong with the kiln. Here are four ways to stop the alarm messages from appearing during routine firings:

Method 1: Test your kiln to find its fastest firing rate and its slowest cooling rate. Then program the controller using rates within the range of the kiln's heating/cooling capacity. Example: If your fastest heating rate is 600° per hour, enter a rate no faster than 600°.

Method 2: Set the deviation temperature to a higher number in the **TEdE** option. The higher the number, the less likely that an alarm message will appear.

Method 3: Set the deviation temperature to 0 in the **TEdE** option. This turns off the **FTH**, **FTC** and **LTdE** alarms (page 19). We do not recommend a 0 setting.

Method 4: Program a segment at **FULL** rate (9999°). This will shut off the deviation alarms for that segment. (However, deviation alarms will continue to work during the hold and all other segments with slower rates.)

CAUTION: The High Temperature Deviation (**HTdE**) alarm shuts off the kiln to prevent an overfire. On controllers with pre-18D software, entering a temperature deviation of 0 turns off this important alarm! On all controllers, entering a **FULL** rate also turns off this alarm for the segment with the **FULL** rate.

Changing the Deviation Temperature

- 1 From **IdLE**, press **OPTIONS** repeatedly until **TEdE** appears.
- 2 Press **ENTER**. Change the deviation temperature. The higher the number, the less likely you will activate the alarms.
- 3 Press **ENTER**. Press **STOP** to return to **IdLE**.

Note: The factory default **TEdE** setting is 100°F / 56°C.

Example: The Fail to Heat code **FTH** appears during a firing when the kiln cannot heat as fast as programmed. The Temperature Deviation **TEdE** is set to 100°F / 56°C. The Fail to Heat code will appear if the temperature is 100°F / 56°C or more below the set point.

SFTY / Maximum Temperature

View the Kiln's Maximum Operating Temperature

From **IdLE**, press **OPTIONS** repeatedly until **SFTY** appears. Press **ENTER**. The temperature displayed is the maximum operating temperature programmed in the Sentry for your kiln. (This temperature is also shown on the kiln's electrical data plate.) It can be altered only at the fac-

tory. The controller will not fire hotter than that temperature. Press **ENTER**. Press **STOP** to return to **IdLE**.

ELEC / Electronics Temperature

Check the Circuit Board Temperature

High temperatures in the switch box can damage the controller circuit board, which is rated for 176°F / 80°C maximum operating temperature. To lower board temperature, use a fan to blow air across the kiln switch box into the louvers. (But do not blow air into the kiln's peepholes.) When firing several kilns, position them at least three feet apart to allow adequate air circulation.

From **IdLE** or while firing, press **OPTIONS** repeatedly until **ELEC** appears. Press **ENTER**. The temperature of the circuit board will appear. Press **ENTER**. Press **STOP** to return to **IdLE**.

CAUTION: Do not operate the kiln if the **ELEC** display is above 158°F / 70°C.

LOCK / Program Lock

Make a Program Tamper-Proof

With Program Lock activated, stored programs cannot be altered or removed from memory. Use Program Lock for repeat firings that you don't want to inadvertently change.

Note: Program Lock does not save a delay setting. While a program is locked, you can enter a new delay.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **LOCK** appears.
- 2 Press **ENTER**. **LO** (locked) or **UN** (unlocked) will appear.
- 3 To change the setting, press **DELAY** three times.
- 4 Press **ENTER**. Press **STOP** to return to **IdLE**.

CFG / Configuration Code

Information for Technicians

From **IdLE**, press **OPTIONS** repeatedly until **CFG** appears. Press **ENTER**. The factory configuration code will appear. Press **ENTER**. Press **STOP** to return to **IdLE**. The configuration code can be changed only at the factory.

SOFT / Software Version

From **IdLE**, press **OPTIONS** repeatedly until **SOFT** appears. Press **ENTER**. The software version will appear. Press **ENTER**. Press **STOP** to return to **IdLE**.

TEST / Element Test

Test the Heating Elements and Relays

This test is useful when measuring the wall receptacle voltage under load, and amperage with an ammeter. On a multiple-zone kiln, the test helps determine if the relays and thermocouples are wired to the correct zones. If you test thermocouples with a cigarette lighter or other heat source, use this option.

Single-Zone Kiln

- 1 From **IdLE**, press **OPTIONS** repeatedly until **TEST** appears.
- 2 Press **ENTER**. **POWR** will appear, alternating with kiln temperature. The elements will turn on for two minutes. Press any key to abort the test.

Multiple-Zone Kiln

- 1 From **IdLE** press **OPTIONS** repeatedly until **TEST** appears.
- 2 Press **ENTER**. **TOP** will appear, alternating with the temperature of the top zone. The elements will turn on for two minutes. Then **MID** will appear, with temperature for the middle zone, and **BOT** with temperature for the bottom zone. (A two-zone kiln shows **TOP** and **BOT** displays only.)
- 3 During the two-minute test, press any key to end a zone test. The controller will then begin to test the next zone.

AOP Outlet

After the above test, kilns equipped with the AOP outlet will display **J3-3** for two minutes to test power to the AOP outlet.

RST / Reset

Reset the Controller to Most Factory Defaults: Perform Only When Requested by a Technician

Reset does the following:

- Selects Type-S thermocouple.
- Selects °F.
- Erases any thermocouple offset.
- Erases User programs stored in memory.
- Changes Temperature Deviation (TEdE) back to the factory setting of 100°F / 56°C.

CAUTION: If your kiln uses a Type-K thermocouple, the Sentry will underfire after a reset! Use the Thermocouple option (page 15) to select Type-K again.

- 1 From **IdLE**, press **OPTIONS** repeatedly until **RST** appears.
- 2 Press **ENTER**. Use the **1** or **2** key to select **NO** or **YES**.
- 3 After selecting one of the above, press **ENTER**. Press **STOP** to return to **IdLE**.

Chapter 7

Error Messages

- Error messages are accompanied by an alarm.
- Non-interrupting messages do not stop the firing. Terminating error messages do.
- FTH, FTC, and LTdE error messages are based upon the adjustable setting in the Temperature Deviation (TEdE) option (page 17).

Note: On controllers with pre-18D software, the HTdE error message is also based on the TEdE option.

Non-Interrupting Error Messages

Press **ENTER** to silence the alarm. (Do not press **STOP** to silence the alarm.) The error message will remain but the kiln will continue firing. Even though the following error messages appear, the kiln will continue its normal operation. The messages are only to alert you that the kiln could not cool or heat as fast as you had programmed. But they will not shut off the kiln or affect the firing in any way.

Definition of “Set Point”

The temperature that the controller is trying to reach, at any given time, is called the set point. During heating or cooling, the set point changes at the rate you programmed. During a hold, the set point remains steady.

FTC / Failed to Cool

- During a cooling-down ramp, the programmed rate is faster than the kiln can cool. The temperature is above the set point temperature by more than the deviation setting. (See Temperature Deviation, page 17.) Program a slower cooling rate.

Note: On controllers with 18D and later software: Use Present Status to compare the actual rate of the current segment with the rate you programmed. (See page 12.)

FTH / Failed to Heat

- During a heating-up ramp, the programmed rate is faster than the kiln can heat. The temperature is below the set point temperature by more than the deviation setting. (See Temperature Deviation, page 17.)

Program a slower rate. Or check for worn or burned out elements, defective relays, low voltage and defective thermocouple.

Note: On controllers with 18D and later software: Use Present Status to compare the actual rate of the current segment with the rate you programmed. (See page 12.)

LTdE / Low Temperature Deviation

- During a cooling-down ramp or a hold, the temperature is below the set point temperature by more than the deviation setting. (See Temperature Deviation, page 17.) Check for worn or burned out elements, defective relays, low voltage and defective thermocouple.

Note: During a firing, Present Status shows the actual firing rate of the current segment instead of the rate you programmed. If you think your kiln is heating or cooling too slowly, compare the rate shown in Present Status with the rate you programmed for that segment. This is another reason you should always keep a written record of your firing programs. (Pre-18D software versions show the programmed rate in Present Status rather than the actual rate. See page 18, SOFT option, to look up the software version.)

PF / Power Failure

PF alternating with normal display means the power failed during firing. After power was restored, the firing resumed.

TC with Lines / Multiple-Zone Kiln Thermocouple Failure

The kiln will continue to fire as long as at least one thermocouple is working. The lines following “TC” represent the position inside the kiln of the thermocouple(s) that failed.

Top line = top thermocouple

Middle line = middle thermocouple

Bottom line = bottom thermocouple

TC⁻ Top thermocouple failed

TC- Middle thermocouple failed

TC₋ Bottom thermocouple failed

TC= Top and middle thermocouples failed

TC₋ Top and bottom thermocouples failed

TC≡ Top, bottom and middle thermocouples failed

On Sentry controllers with pre-18D software, “TC” is followed by a number and a line. You can check the software version of your controller by using the SOFT Option. See page 18.

Multiple-zone controllers with 18D or earlier software:

TC 1⁻ Top Thermocouple Failed

TC 2- Middle Thermocouple Failed

TC 3₋ Bottom Thermocouple Failed

Terminating Error Messages

HTdE, **ETH**, **FAIL**, **FTL** and **TCdE** error messages turn off the kiln and flash the following:

- Total firing time in hours and minutes
- The kiln shutoff temperature
- The current kiln temperature

---- / No Thermocouple

After the controller was plugged in, it could not detect a thermocouple.

BAdP / Bad Programming

Causes:

- A program has been entered with 0 rate in the first segment.
- When you press **START**, all programmed temperatures are below the current kiln temperature.

ETH / Electronics Too Hot

- The circuit board temperature is above 176°F / 80°C.

To lower board temperature, use a fan to blow air across the kiln switch box into the louvers. (But do not blow air into the kiln's peepholes.) If you have more than one kiln in the room, place them at least 3 feet apart. Never allow the firing room temperature to exceed 110°F / 43°C. (Measure room temperature 3 feet away from the kiln.)

FAIL / Thermocouple Failure

The controller is no longer receiving voltage from the thermocouple. Causes:

- Defective thermocouple
- Disconnected thermocouple lead wires
- Defective board
- Electrical noise

FTL / Firing Too Long

- The temperature change is less than 27°F / 15°C per hour and the firing time is two hours longer than the current segment was programmed to fire. This message can appear during heating-up or cooling-down segments. **FTL** sometimes appears because the cooling segment was programmed faster than the kiln could naturally cool down.
- **FTL** will flash if you program a cooling segment temperature that is below room temperature. When **FTL** appears, press **STOP**.

Check for worn or burned out elements, defective relays, low voltage and defective thermocouple. Reprogram a slower rate in heating-up and cooling-down segments.

Note: To avoid **FTL** messages, try firing the kiln at a slower rate.

Note: During a firing, Present Status shows the actual firing rate of the current segment instead of the rate you programmed. If you think your kiln is heating or cooling too slowly, compare the rate shown in Present Status with the rate you programmed for that segment. This is another reason you should always keep a written record of your firing programs. (Pre-18D software versions show the programmed rate in Present Status rather than the actual rate. See page 18, *SOFT* option, to look up the software version.)

HTdE / High Temperature Deviation

Causes:

- During a heating-up ramp or a hold, the temperature is 100°F / 56°C above the programmed temperature.
- During a cooling-down segment, the temperature is 100°F / 56°C above the segment's starting temperature.
- A fast rate caused the controller to overshoot the target temperature.
- A relay is stuck in the closed position sending power to the elements.

See "Power Failures," next page.

Note: You can disable the HTdE alarm for a segment by programming a FULL rate (9999°). HTdE will continue to operate during the hold and in all other segments that have slower rates.

PF1 / Power Failure

The power failed during a controlled cooling segment. The kiln temperature was below the last active cooling segment temperature when the power came back on. The kiln will not resume firing. See "Power Failures," next page.

PF 2 / Power Failure

The power failed. The kiln temperature was below 212°F / 100°C when the power came back on. The kiln will not resume firing. See "Power Failures," next page.

PF 3 / Power Failure

The power failed. The temperature dropped 72°F / 40°C while the power was off. The kiln will not resume firing. See "Power Failures," next page.

TC 2 / Thermocouple Failure

The thermocouple of a single-zone kiln failed while the controller was at **IdLE**.

TCL / Thermocouple Lag

The heating rate is slower than 9°F / 5°C per hour and the kiln temperature is more than 100°F / 56°C away from the programmed temperature. The TCL becomes inactive above 500°F/260°C.

Causes:

- On kilns that use a portable controller, the thermocouple fell out of the firing chamber.
- A bare spot on the thermocouple lead wires has touched a grounded object inside the kiln switch box causing the thermocouple to short out.
- **TCL** will flash if you program a cooling segment temperature that is below room temperature. When **TCL** appears, press **STOP**.
- Check for worn or burned out elements, defective relays, low voltage and defective thermocouple.

Note: *The TCL alarm is available only on software version 18D or later. You can check the software version of your controller by using the SOFT Option. See page 18.*

Lld / Missing Connector Pin

On the back of the Sentry circuit board, at the top right side, is a small two-pin terminal. If the connector on that terminal is missing, **Lld** will appear in the display during firing. The elements will not turn on. (If the two-pin connector is missing, you can buy another from a computer supply store.)

TCdE / Uneven Multiple-Zone Temperatures

The zones of a multiple-zone kiln are firing unevenly. Causes:

- A burned out element or relay
- The thermocouples and elements are improperly wired. A thermocouple is turning on the elements to the wrong zone. For instance, if the top thermocouple turns on the bottom elements, the kiln will fire out of balance. When zones are out of balance by 180°F / 100°C, **TCdE** will appear in the display.

Visually compare the wiring of the thermocouples, relays and elements in your kiln to the kiln's wiring diagram. Also, use the Element Test option shown on page 18.

TCR / Thermocouple Leads Reversed

Check that the thermocouple lead wires are connected to the correct terminals. See your wiring diagram.

Power Failures

The Sentry handles a power failure in two ways:

- 1 After a brief power failure, the controller continues firing as before. It shows a normal temperature display alternating with **PF**.
- 2 After an extended power failure, **PF 1** **PF 2** or **PF 3** will appear. The kiln will NOT resume firing.

The kiln will remain turned off after a power failure under these conditions:

- The kiln will remain off if the temperature is below 212°F / 100°C when the power comes back on.
- The kiln will remain off if the temperature dropped 72°F / 40°C or more.

When the Sentry aborts a firing after a power failure, the display will show the following:

- **PF 1** **PF 2** or **PF 3**
- Total firing time before power failed
- Temperature at the time of power failure
- Current kiln temperature

To resume firing, press **ENTER**. The kiln will begin firing again from its present temperature. For example, the kiln reached 1000°F / 538°C when power failed. The temperature is 800°F / 426°C when you turn the kiln back on. Firing will resume from 800°F / 426°C. You need not cool the kiln to room temperature before starting a ceramic firing over unless you decide to use new witness cones.

When you resume firing by pressing **ENTER**, the controller begins firing in the first segment that has a higher target temperature than the current kiln temperature. However, if the power failed during a ramping down (cooling) segment, the controller will resume firing from the same cooling segment.

When the Kiln Shuts Off Too Soon

Ceramic Firings

If the kiln fires to completion before the pyrometric witness cone bends, you can turn the kiln back on and keep firing. Simply program a hotter temperature. Then from **IdLE**, press **START**. The kiln will begin firing, taking up where it left off.

Note: *By looking at the witness cones through a peep-hole, you will know if the kiln shuts off too soon.*

Wrong Thermocouple Type

If a Type-K thermocouple is installed on your kiln, but Type-S is selected in Options, the kiln will continually underfire by a wide margin. (The kiln will overfire if Type-S is installed and Type-K is selected.) See page 15 to check the thermocouple type selected in Options.

Appendix A: Display Messages

Message Definition Page Reference

AbRT **Abort** 5
The firing was stopped.

ALAR **Alarm** 8, 10, 11, 12

ALAR appears either when you are entering an alarm temperature or when the alarm is sounding during a firing. To stop an alarm, press any key except STOP. If the alarm goes off when you first begin firing, it is because it was set for a lower temperature than the present temperature.

AOP **Auxiliary Output** 8, 10, 16

The AOP option is for kilns equipped with a special-order kiln switch box receptacle called the Auxiliary Output.

bAdP **Bad Programming** 20

This message appears when a firing has been programmed with 0 rate in the first segment or when all target temperatures are lower than the current kiln temperature.

CFG **Configuration Code** 18

This is an option that shows the factory configuration code for your Sentry. This is for technicians who call the factory for support.

CHG- **Change °F / °C** 15

Choose between operation in degrees F or degrees C.

COST **Electrical Rate** 12, 16

Enter the electric rate shown on your electric bill. Example: 10.25 cents per KWh is entered as 10.25.

CPLT **Completed Firing** 5, 9

This means the firing completed normally as programmed. These three messages will also cycle one after the other: firing time in hours and minutes, the temperature of the last segment, and the current kiln temperature.

DELA **Delay** 8, 11

DELA is a timer that starts the kiln later. Delay time appears in hours and minutes.

°F 1 or **°C 1** **Target Temperature** 6

This prompt is asking for a target temperature. The number is the segment of the program.

DIFF **Temperature Difference** 14

This option shows the maximum temperature spread between zones in a multiple-zone kiln.

ELEC **Electronics Temperature** 18

The Sentry circuit board is rated for operation at temperatures up to 176°F / 80°C. When the circuit board gets hotter, the Sentry shuts off. The ELEC option shows you the temperature of the circuit board.

Message Definition Page Reference

ETH **Electronics Too Hot** 20
The Sentry circuit board is too hot, so the kiln shut off.

FAIL **Thermocouple Failed** 5, 20

The thermocouple failed. This can be due to a broken thermocouple, loose thermocouple connection on the back of the controller, disconnected thermocouple wire, or a defective controller.

FAN **Vent Fan** 16

The Fan option, accessed through the OPTIONS key, is for kilns equipped with a special-order kiln switch box receptacle called the Auxiliary Output.

FN 1 **Fan** 8

If your kiln has the optional AOP outlet (for a kiln vent), the FN prompt will appear for each segment during programming. It is asking if you want the vent on or off for that segment.

FTC **Failed to Cool** 17, 19

This error message means the kiln cannot cool as fast as the cooling that you programmed.

FTH **Failed to Heat** 17, 19

The kiln cannot heat as fast as you programmed.

FTL **Firing Too Long** 20

The temperature rise is less than 27° / 15°C per hour and the firing time is two hours longer than the current segment was programmed.

FULL **Full Speed** 7, 8, 17

The rate, or temperature change per hour, is maximum.

Hd 1 **Temperature Hold** 8

When this message appears during programming, it is asking you if you want to hold, or maintain, the target temperature of that segment. If so, enter the length of hold time in hours and minutes (Example: 1 hour 20 minutes = 01.20). The number after Hd is the segment number. Each segment in a firing is numbered.

HTdE **High Temperature Deviation** 17, 20

During a heating-up ramp or a hold, the temperature is 100°F / 56°C above the programmed temperature.

ID **Computer ID** 17

The ID option is for connecting the Sentry to a personal computer.

IdLE **Ready to Begin** 5

The Sentry must display the IdLE message before you can begin firing or programming.

Message	Definition	Page Reference
KW	Kilowatts	12, 16
	The controller can figure the cost to fire your kiln if you supply your kiln's wattage. (See the data plate on the switch box.) Divide wattage by 1000 to get kilowatts. Enter that amount: 10,800 watts ÷ 1000 = 10.8	
Lld	Missing Pin	21
	When Lld appears, a two-pin connector on the back of the board is missing.	
LOCK	Program Lock	18
	With this option activated, a stored program cannot be altered or removed from memory.	
LTdE	Low Temperature Deviation	19
	This message appears when the kiln is below the temperature deviation setting in the TEde option.	
PF 1	Power Failure	20
	The power failed during a controlled cooling segment. The kiln temperature was below the last active cooling segment temperature when the power came back on.	
PF 2	Power Failure	20
	The power failed. When power came back on, the temperature was below 212°F / 100°C.	
PF 3	Power Failure	20
	The power failed and the temperature dropped 72°F/40°C.	
PF	Power Failure	21
	There was a power failure during firing. The kiln continued firing after the power came back on.	
RA 1	Rate	7
	RA 1, RA 2, RA 3, etc., appear during programming, in Program Review, and in Present Status. When RA 1, 2, 3, etc. appear during programming, the controller is asking you for firing rate for each segment. Rate means how fast the firing progresses, in degrees of temperature per hour. Every segment must have a firing rate. The number after RA is the segment number. Each segment in a firing is numbered. Program Review shows firing rate after RA 1, 2, 3, etc. In Present Status, RA 1, 2, 3, etc. means the segment that the firing is in at that moment.	
RST	Reset	18
	The RST option erases a thermocouple offset, selects °F operation, erases stored programs, and selects Type-S thermocouple. Note that if you use Reset, and your kiln is equipped with a Type-K thermocouple, you must use the TC option to select Type-K. (Reset selects Type-S as a safety precaution. If you had a Type-S thermocouple and Reset selected Type-K, your kiln would overfire. On the other hand, if you had a Type-K thermocouple, Type-S selected would underfire your kiln, which is better than overfiring it. The K-Type thermocouple is standard on most kilns.)	

Message	Definition	Page Reference
SFTY	Safety	17
	This is the maximum temperature the Sentry is programmed for your kiln. It can be altered only at the factory.	
SKIP	Skip Segment	13
	If you press the Skip Segment key during a firing, SKIP will appear. If you press the key again, the firing will skip to the next segment.	
SOFT	Software Version	18
	This option shows the version of software loaded into your Sentry.	
STRT	Firing Started	8
	This appears when firing begins. Do not be concerned if it takes a moment for the relays to turn on. The Sentry is processing data.	
T123	Zone Temperatures	14
	This option shows temperatures in each zone.	
TC	Thermocouple Type	15
	Choose between types K, S, or R thermocouple. It is important to select the correct type, or the controller will not read temperature accurately.	
TCdE	Uneven Temperature	21
	This is an error message for multiple-zone kilns. It means the temperatures of the zones are out of balance by 180°F / 100°C. This is usually caused by a miswired kiln or by a defective relay.	
TCL	Thermocouple Lag	21
	The heating rate is slower than 9°F/5°C per hour and the kiln temperature is more than 100°F / 56°C away from the programmed temperature.	
TCOS	Thermocouple Offset	14
	Adjust the controller's temperature to compensate for temperature drift, or aging, of a thermocouple.	
TCR	Thermocouple Reversed	21
	The thermocouple wires are reversed.	
TEdE	Temperature Deviation	17
	The Sentry includes error messages to warn you that the kiln is not maintaining the programmed temperature. The sensitivity of the error messages is based on a temperature entered in the TEde option.	
TEST	Element Test	18
	This option is for testing the elements and thermocouples. If you test a thermocouple with a lighter, the temperature display responds faster during Test than during IdLE display.	
USER	User Program	7
	During programming, the USER prompt is asking you where you want to place the program in memory. The Sentry has 9 spaces in memory. Keep a written record of the programs 1 - 9 in memory.	

Appendix B: Upgrading Instructions

Upgrading the DTC 100, 600, 800 & 1000 Series to the Sentry


1 Unplug the kiln or disconnect the power. Remove the 4 screws holding the controller faceplate to the switch box. Gently remove the old controller.

2 Disconnect the wires from the old controller.


3 If your kiln is top-loading and originally came with a DTC 100 or 600, the heat shield inside the switch box may need to be moved to give more clearance for the new Sentry controller. Measure the space between the heat shield and the front of the box. If the space is less than 1 $\frac{3}{4}$ " , remove the screws that hold the bottom of the heat shield. These screws are on the sides near the louvers. Drill new holes in the switch box next to the bottom 2 holes used for the heat shield. Move the bottom of the heat shield back and fasten screws in the new holes.



4 Thread the Sentry wiring harness into the switch box by inserting it in the opening where the controller goes. Let the end with the plugs hang out of the box.




5 Remove the switch box from the kiln by removing the screws holding the box to the kiln.



6 The red wire from the old controller connects to the relay(s). The red wire in the Sentry wiring harness goes to the same relay terminal. (See diagram, facing page.) You will notice that the red Sentry wire has 3 push-on connectors with jumper wires. If your kiln has 3 relays, you will use all 3 push-on connectors, 1 for each relay. If you have 2 relays, cut off the last terminal and jumper wire. If your kiln has 1 relay, cut off 2 push-on connectors. Cut the wire close to the terminal that remains (see next photo).

The extra wires tied to the harness are for multiple-zone kilns and the optional AOP electrical outlet. The green grounding wire is connected only if you use a computer interface.

CAUTION: *Cut off the extra terminal(s) and jumper wire(s) unless they attach to relays. Unconnected wires that touch a grounded object can damage your controller!*




7 Attach the red wire terminal(s) to the relay(s). Follow steps 6 and 7 for the black wire, which also goes to the relays.


8 Note how the white, orange, and blue wires of the old controller are connected to the transformer. Removing and replacing one wire at a time, connect the Sentry white, orange, and blue wires to the transformer the same way. (See Transformers, next page. Cut off the extra blue wire terminal if your transformer doesn't need it.)

9 Remove the old wiring harness from the switch box. With the thermocouple wires and the Sentry connection plugs hanging out of the front of the switch box, move the box into place on the kiln. Arrange the wires so that when the switch box is fastened to the kiln, the wires and wire nuts will not touch an element connector or the kiln case. Install the screws that hold the switch box to the kiln.

10 Straighten the ends of the thermocouple wires.




Lever type connectors: if the wire is too thick, it will break the lever. Do not force the lever downward.



The button-type thermocouple connector: Press down, then insert wires.


Attach them to the thermocouple terminals on the bottom of the Sentry. (Use the center connectors if your kiln has only one thermocouple.) Match the color coding. Make sure the thermocouple wires are tight and that there is no short.

11 Attach the two plugs to the back of the Sentry controller. Carefully insert the Sentry into the controller opening on the switch box. Install the 4 corner screws.




Inserting the plugs on the back of the Sentry.


How to Wire the Sentry



Upgrading from the DTC-Series Controllers



Wiring Single & Multiple Relays



The red wire and black wire contain extra push-on terminals for kilns with three relays. If your kiln has one or two relays, cut off the extra terminal(s) and wire(s). Spare terminals or wires that touch a grounded object could damage your controller!

Appendix C: User Program Records

Date _____

User Program 1

Rate °/Hour	Target Temperature	Hold Time Hours.Mins	Optional Fan On / Off
rA1	1	Hd1 .	
rA2	2	Hd2 .	
rA3	3	Hd3 .	
rA4	4	Hd4 .	
rA5	5	Hd5 .	
rA6	6	Hd6 .	
rA7	7	Hd7 .	
rA8	8	Hd8 .	
rA9	9	Hd9 .	
rA10	10	Hd10 .	
rA11	11	Hd11 .	
rA12	12	Hd12 .	
rA13	13	Hd13 .	
rA14	14	Hd14 .	
rA15	15	Hd15 .	
rA16	16	Hd16 .	
rA17	17	Hd17 .	
rA18	18	Hd18 .	
rA19	19	Hd19 .	
rA20	20	Hd20 .	

Date _____

User Program 2

Rate °/Hour	Target Temperature	Hold Time Hours.Mins	Optional Fan On / Off
rA1	1	Hd1 .	
rA2	2	Hd2 .	
rA3	3	Hd3 .	
rA4	4	Hd4 .	
rA5	5	Hd5 .	
rA6	6	Hd6 .	
rA7	7	Hd7 .	
rA8	8	Hd8 .	
rA9	9	Hd9 .	
rA10	10	Hd10 .	

Date _____

User Program 3

Rate °/Hour	Target Temperature	Hold Time Hours.Mins	Optional Fan On / Off
rA1	1	Hd1 .	
rA2	2	Hd2 .	
rA3	3	Hd3 .	
rA4	4	Hd4 .	
rA5	5	Hd5 .	
rA6	6	Hd6 .	
rA7	7	Hd7 .	
rA8	8	Hd8 .	
rA9	9	Hd9 .	
rA10	10	Hd10 .	

Date _____

User Program 4

Rate °/Hour	Target Temperature	Hold Time Hours.Mins	Optional Fan On / Off
rA1	1	Hd1 .	
rA2	2	Hd2 .	
rA3	3	Hd3 .	
rA4	4	Hd4 .	
rA5	5	Hd5 .	
rA6	6	Hd6 .	
rA7	7	Hd7 .	
rA8	8	Hd8 .	
rA9	9	Hd9 .	
rA10	10	Hd10 .	

Index

- A**
 - AbRT, 5, 22
 - Add Time, 1, 11
 - ALAR, 22
 - alarm, 1, 6, 8, 9, 10, 11, 12, 16, 17
 - AOP, 1, 8, 10, 16, 18, 22
 - Auxiliary Output, 16, 22
- B**
 - baby monitor, 6, 12
 - bAdP, 20, 22
- C**
 - Celsius, 5, 15
 - CFG, 1, 18, 22
 - CHG-, 1, 15, 22
 - clicking, 2, 12
 - controlled cooling, 8, 9, 13
 - COST, 1, 12
 - CPLT, 5, 9, 17, 22
- D**
 - DELA, 8, 22
 - Delay, 1, 11, 18
 - DIFF, 1, 14
- E**
 - ELEC, 1, 18
 - electrical cost, 2, 12
 - Element Test , 1
 - ETH, 20
- F**
 - Fahrenheit, 5, 15
 - FAIL, 5, 13, 20
 - firing schedule, 10
 - FN, 10
 - FTC, 17, 19
 - FTH, 17, 19
 - FTL, 20
 - FULL, 8, 13, 17
- G**
 - glass, 9, 11, 12, 13
- H**
 - heat treating, 10, 12
 - hold, 6, 8, 11, 13
 - HTdE, 20
 - humidity, 5
- I**
 - Id, 1, 17
 - IdLE, 5, 22
- J**
 - J3-3, 18
- K**
 - kilowatt-hour, 16
 - kilowatts, 17
 - KW, 1, 12
- L**
 - LId, 21
 - LOCK, 1, 18, 23
 - LTdE, 17, 19, 23
- M**
 - memory, 7
 - multiple-zone, 1, 2, 13, 18
- O**
 - over-fire, 2, 4, 6
 - overshoot, 10
- P**
 - peephole, 11
 - PF, 19, 23
 - PF 2, 20, 23
 - PF 3, 20, 23
 - PF1, 20
 - power failure, 4, 20, 21
 - Present Status, 1, 12, 19, 20
 - Program Lock, 7, 9, 18
 - Program Review, 1, 9, 10
 - programming, 8
 - pyrometer, 14
- R**
 - rA 1, 7, 8
 - rate, 1, 7, 10, 12, 16, 17, 19, 20
 - relay, 24
 - Reset , 1
 - RST, 1, 18, 23
- S**
 - safety, 4
 - segment, 1, 6, 7, 8, 9, 13
 - set point, 17, 19
 - SFTY, 1, 17, 23
 - SKIP, 13, 23
 - Skip Segment, 1, 13
 - SOFT, 1, 2, 18, 23
 - software version, 2
 - STOP, 4, 7, 8, 12, 14, 15
 - STRT, 23
- T**
 - T123, 1, 14, 23
 - target temperature, 6, 8, 9, 10, 13
 - TC, 1, 23
 - TC 2, 20
 - TCdE, 20, 21, 23
 - TCL, 21
 - TCOS, 15, 23
 - TCR, 21, 23
 - TEDE, 17, 23
 - Temperature Deviation, 1, 9, 17
 - TEST, 1, 18, 23
 - thermocouple, 1, 2, 5, 13, 14, 15, 18, 19, 20, 21, 23
 - Thermocouple Offset, 1, 14
 - thunder storms, 5
 - TnF 2, 2
- U**
 - USER, 7, 8, 23
- W**
 - wiring harness, 24

Appendix D:

Sentry Ramp-Hold Shorthand Instructions

After you press the keys in the left column, the message to the right will appear.

KEYS TO PRESS	DISPLAY	COMMENTS
<u>PROGRAM AND FIRE THE KILN.</u>		
Apply power to kiln	IdLE	Press Enter if IdLE does not appear.
4	USER	Enter program number.
A number from 1 to 9	1	Program number appears.
ENTER	RA 1	Enter rate of segment 1.
Rate	0200	Rate appears.
ENTER	°F 1	Enter temperature of segment 1.
Temperature	2000	Temperature appears.
ENTER	Hd 1	Enter hold time.
Hold time (0 if none)	00.00	Hold time appears.
<u>Repeat for other segments. Enter rate of 0 for 1st segment not needed.</u>		
ENTER	IdLE	The kiln is ready to fire.
ENTER	STRT	Kiln is now firing.
<u>SELECT AND FIRE A STORED USER PROGRAM.</u>		
Apply power to kiln	IdLE	Press Enter if IdLE does not appear.
4	USEr	Select a program number.
A number from 1 to 9	1	Displays the number you selected.
ENTER	RA 1	
STOP, STOP	IdLE	Selected program is ready to fire.
ENTER	STRT	

The kiln is now firing. Press 6 for Program Review.